



Operating Manual

Classic Solar Absorber

1. Initial operation at the beginning of the season
 - D Close the Draining cap, piping
 - D Close pump draining; if higher than water level of the pool, than open the pump in the prefilter area and fill in water in order to avoid dry operation of the pump
 - D In case of 3 –ways valve operation there are no special arrangement required.
 - D Rinse thoroughly with fresh water 5 minutes
 - D Switch on the Control System (manual mode, respectively automatic mode)
 - D Clean the solar absorber (manually , hose down with water hose or high pressure cleaner (max. 20 bar respectively 10 cm distance))
2. Salt installations may be used only in a combination with a heat changer (Titan)
3. Shock – chlorination only in the evening
 - D Switch off the solar installation before
 - D And switch the system on not until the morning
4. Clean occasionally the absorber; hose down with water hose or high pressure cleaner (max. 20 bar respectively 10 cm distance))
5. Repair absorber leakage with repairing set
6. End of the season
 - D Rinse with fresh water after the filter installation is switched off for some minutes
 - D If pump operation, not 3-ways valve, than open the pump-emptying valve and empty it.
 - D Open the Draining cap on the roof and close it again at the beginning of the season.
 - D Switch off the controller; don't plug it out from the power supply.

If you cannot repair a fault on your own, your swimming pool specialist is to your disposal.